TORUN

Best Practices for Healthcare Lighting

Behavioral Health



RICHARD

Regional Manager - West



Regional Manager - Central



CHADNational Sales Manager



CHRIS
VP Sales & Marketing




Key Focus Areas
















Behavioral Health by the Numbers (Pre-COVID)

1 in 5

Americans lives with a behavioral health disorder

+31%

Increase in overall U.S. suicide rate since 2001

In the Hospital

1 in 8

Emergency Dept. visits involves behavioral health conditions 415%

Increase in ED visits due to suicidal ideation

#1

Mood disorders are the leading cause of hospitalization for Americans under 45

In Behavioral Health Facilities / Wards

80%

of inpatient suicides in the U.S. occur among psychiatric inpatients +12.3%


Annual increase in beds in behavioral residential treatment centers (RTCs) **55%**

of nurses in psychiatric facilities report experiencing physical assault

Sources: https://www.ncbi.nlm.nih.gov/pubmed/23433725/, https://www.ncbi.nlm.nih.gov/pubmed/23433725/, https://www.nami.org/learn-more/mental-health-by-the-numbers, https://www.jointcommissionjournal.com/article/S1553-7250(18)30253-8/fulltext



The COVID-19 Effect



Increased Risk of Infection

"In contrast to general healthcare settings, psychiatric facilities may experience unique challenges in prevention and infection control"

> - SAMHSA COVID-19 Interim Considerations for State Psychiatric Hospitals, May 2020

Recommended Guidelines:

- Quarantine on intake
- Limit movement of COVID patients
- Segregate areas or floors
- Curtail visiting hours
- Ensure frequent cleaning & disinfecting

Sources: https://www.samhsa.gov/sites/default/files/covid19-interim-considerations-for-state-psychiatric-hospitals.pdf




Behavioral Health Facilities



Dedicated Psychiatric Hospital



Behavioral Wing in a General Hospital



Residential Treatment Center



Top 3 Goals in Behavioral Health Lighting

- (1) Prevent suicide and self-harm
- 2 Prevent harm to others
- (3) Create an environment for healing



Behavioral Health Design Guide

LIGHTING REQUIREMENTS





The use of 2'x4' light fixtures creates an institutional appearance in patient rooms.

"Preference is for using either round or oval, vandal-resistant fixtures for general illumination and recessed security downlights with polycarbonate lenses over the beds for reading lights."





Risk Levels in Behavioral Facilities



Level I

Staff & Service Areas







Counseling & **Interview Rooms**





Level III

Corridors, Lounges, **Activity Rooms**





Level IV

Patient & Toilet Rooms





HIGHEST RISK

Level V

Admission &

Seclusion Rooms








Risk Levels in Behavioral Facilities



Staff & Service Areas



Corridors, Lounges,
Activity Rooms

Patient & Toilet Rooms

Admission & Seclusion Rooms











LOW RISK

No patient use or constantly supervised

MEDIUM RISK

Patient access is controlled, or use is supervised with no solitary and/or unsupervised use

HIGH RISK

Areas with solitary and/or unsupervised patient use










Behavioral Fixture Families



Recessed Rounds





Recessed Luminaires for Behavioral Health







Virginia Treatment Center for Children (VTCC)

Downlights: LRV-07469

Quantity: 243 units

CCT: 3500K

Output: 1500L



Mental Health

In the End-User's Words:

"I want to thank and acknowledge the inpatient team and CannonDesign project team who has consistently placed quality and safety first."

- Alexandria Lewis, Exec. Dir., VTCC





Available Color Temperatures









Additional Listings & Options







St. Clare's Hospital – Behavioral Health

Downlights: MRV-06858

Quantity: 80 units

Output: 1500L





In the Specifier's Words:

"We achieved a less institutional, less prison-like design."


- Lori Klein, Principal & Director of Design, Posen Architects








Behavioral Health Series: Key Design Features









SINGLE PIECE, SELF-FLANGED TRIM


TAMPER-RESISTANT HARDWARE

HIGH-STRENGTH DUAL LENS

0.1875" high strength acrylic above 0.22" polycarbonate below



Behavioral Health Downlight: What's Inside



All-Aluminum Housing

- 1. Cooler operation
- 2. Rust proof and corrosion resistant

Internal Bracketry & Construction

- 1. Tight seal between trim flange and ceiling
- 2. No access into fixture




St. Clare's Hospital – Behavioral Health

Downlights: MRV-06858

Quantity: 80 units

CCT: 3000K

CRI: 90+



2. Offset spartan furnishings with architectural lighting


NightLights: MNS-05924-26

Quantity: 24 units











Behavioral Fixture Families
















Wayfinding Luminaires for Behavioral Health









Virginia Treatment Center for Children

Downlights: MRV-07840

Quantity: 144 units







StepLights: LNT-03096-RA-26


Quantity: 64 units









"A Healing Sanctuary that Supports Rehabilitation Without Stigma"






Behavioral Fixture Families










Observation Lighting: What's Behind That Door?








Kirlin Night-Time Observation Light

- Circadian-Supporting Orange/Yellow or Orange/Red suppress blue light
- Switched outside the room
- Permits regular assessment of patient's status without entering the room
- IK10 rated, with ligature-resistant construction approved by the NYS OMH
- IP66 and ISO 5 / Class 100 Clean Room rating optional




MRV-06864-OYF






MRV-06864-ORF



Night-Time Observation Light: MRV-06864








Behavioral Fixture Families









Surface · Recessed

INFRALED PRO 35V: Motorized Exam


INFRALED® PRO







- 35° Tilt, 360° Rotation
- Fully Recessed System
- Ultimate Infection Control
- Cool LED Beams, 95+ CRI
- Wall and Remote Controlled
- Adjustable Direction & Intensity
- IK10 Impact Resistant Trim with Poly Lens
- 4,090 fc (44,024 lux) on Task (Single Fixture)







INFRALED PRO 35V: Motorized Exam




Remote Control (PRO-REMOT)



Ceiling Mounted Infrared Sensor (PRV-SENSR)



Wall Control Panel (PRO-WALLC)



Controls are safely mounted outside of patient space, using tamper-proof remote sensor.



Behavioral Fixture Families
















White 2'x2' Panels for Behavioral Health



Features


- Super shallow fixture depth
 - Surface: 25%"
 - o Recessed: 23/8"
- 1500L or 2500L output
- 0-10V or Triac dimming to 1% or 10%
- IK10 impact resistant with 0.22" poly environment-side
- Tamper-resistant hardware
- Infection Control: Antimicrobial Finish
- CCT: 3500 K 4100 K
- 90+ CRI

St. Clare's Hospital – Behavioral Health






Behavioral Fixture Families



Recessed Rounds





Surface · Recessed




Surface · Recessed

Scenic 2'x2' Panels for Behavioral Health



Recessed: MRV-22865-A01




Soothing & Distracting "Skylight" Effect

Select from 14 standard images or submit your own






Vandal & Ligature-Resistant Design





Behavioral Fixture Families



Recessed Rounds






Encouraging Safety, Health, & Wellness

Kirlin's behavioral health lighting is

safe and comforting





designed for inpatients, not inmates





