

CATALOG #		TYPE	
JOB NAME	WATTAGE	VOLTAGE	

14" LED 1300 LUMEN SERIES **20 WATT**

MSR-14100

SmartLED™ MRI Lighting Systems

Round Surface Mount Decorative Sconce

Central Glow Panel • Edge Glow White Standard • Colors Optional

Up to 90,000 Hour Life (L70) • LM-80 Qualified





Must Use:

- Kirlin MRI LED Luminaires
- SmartSupply™ LPS-1220A
- SmartFilter™ RFI-3100D

Specifications

LED Light Engine

- 20 watt LED array. 3500°K.
- CRI: 80+. Up to 90,000 hour life (L70**).
- · Fully sustainable; removable for servicing.

Thermal Management System

 Aluminum components and housing maximize cool operation and long life while minimizing maintenance.

SmartSupply™ (Remote Power Supply) Required - Order Separately

- Digitally controlled. Drives up to 2 soon nartSupply has
- % full range dimming in t
- LPS-†220A: Compatible with 0-1 dimming controls. See vendor qualified list in the owner's manual.
- · Suitable for dry, non-plenum location with ambient temperature range of -2 (-4°F) to 40°C (104°F). 115 - 277V;
- For more information, see specif for LPS-1220A.

SmartFilter™ (RFI / EMI Filter) Required - Order Separately

- Protects up to 3 SmartSupply channels
- For more information see spe for RFI-3100D.

SmartPowe

- For more informa

- decorative brushed aluminu (10.5" diameter) with clear
- ntemporary button finials.
- ushed Anodized Aluminum (a) and shallow 21/2" inconspicuous depth meets all Odol operation: Extends life of all components.

- Optional white, white microbial:
- Fully sustainable: Entire luminaire, including light engine, is modular and easily serviced.

- equires minimum 18 AWG twisted pair shielded wire from SmartSupply™ to sconce.
- Universal back plate mounts to any <mark>nagn</mark>et<mark>ic octagon</mark> or 4" square J-box (by

, C-UL (Canada) Listings

ry locations, covered ceilings / wall.

CE & FCC Compliance

- Meets IEC/EN 60601-1-2 electromagnetic compatibility standard for medical electrical equipment.
- FCC Part 15 certified for EMI/RFI emissions.



FIVE YEAR Limited Warranty

Complete standard fixture.

Use of SmartSupply™ and SmartFilter™ REQUIRED or Kirlin warranty is null and void

F© (E E

L70** for Kirlin Luminaires 90,000 hours In Open Space * *Hours at 70% lumen maintenance

THE KIRLIN COMPANY

3401 EAST JEFFERSON AVENUE • DETROIT, MICHIGAN 48207-4232 (313) 259-6400 • Fax: (313) 259-9409 or (313) 259-3121 • www.kirlinlighting.com

CATALOG NUMBER

MSR-14100



Dimensions



Options

Ring and Surface Housing

- -30 White baked enamel finis for ring and housing.
- -35 Natural Aluminum baked enamel finish instead for ring and housing.
- -38 Black baked enamel finish instead for ring and housing.
- -94 Custom color/finish for ring and housing. Specify. Consult factory.
- -BG Anti-microbial Kirlin BioGard™ white (only) finish for ring and housing.

Inner Lens Color

- -BL Blue filter.
 -CF Custom filter color (Rosco). Specify.
- GN Green filter.
- -OR Orange filter.
- -RA Red amber filter.
- -RE Red filter.
- -YE Yellow filter.

Other

 Cl Custom image (color / logo) added to center field of sconce.

3 Steps To "Artifact-Free" Imaging

- 1. Use complete Kirlin SmartLED™ MRI system: luminaires, filters, drivers
- 2. Use a minimum #18 AWG twisted, shielded pair wire
- Use a 0-10V wall box dimmer that is approved for use with SmartSupply[™] (consult Owner's Manual); wall dimmers must be located outside of room shield and must not be filtered through RFI-3100D SmartFilter[™]

SUBMITTAL DATA

APPROVAL STAMP

JOB NAME

TYPE

WATTAGE VOLTAGE

CATALOG NUMBER

option will replace or repair such fixture or refund the purchase price on presentation y is supplied to the buyer in place of all other warranties, expressed or implied. Seller will render the warranty void.

UNITED WARRANTY: CATALOGED KIRLIN FIXTURES ARE WARRANTED FREE OF DEFECTS IN WORKMANSHIP OR MATERIAL FOR THREE YEARS FROM DAT DR PURCHASE, INSTALLED TO N.E.C., IN NORMAL USE, Manuacturer at his United to the long of the purchase and defended from the damage, and the office of reflect of reflects by purchased or any present Trist warrant obes not warrant as to metablished from the damage, and conditionate use to make a system of the damage, and the damage, and the damage, and the damage, and defended from the damage, and defended from the damage, and damage of the damage, and defended from the damage, and damage of the damage, and damage of the dam